



Instructions

- Drill (2) $\frac{1}{4}$ " holes in doggydocks mounting board as per drawing in Fig. 1.
- Position mounting board so the edge of the board is even with the edge of the dock, or pool deck.
- Once the mounting board is positioned, mark where the holes are to be drilled in the concrete.
- Move the doggydocks unit.
- Drill (2) $\frac{1}{4}$ X 2.5" Deep holes in the concrete.
- Make sure hole is clean and free of any debris and dust.
- Fill hole with epoxy.

- Place threaded rod through holes in mounting board and concrete.
- Remove any excess epoxy.
- Place the doggydocks over the threaded rod and move it down the threaded rod until they are in contact with the mounting board, but do not tighten
- Allow epoxy to set for 12 hours
- Tighten the nut so there is no movement in the mounting board
- Cut the threaded rod so it is flush with the top of the nut

Option:

To make sure the threaded rod stays plumb. Make a cardboard template, and cut holes in cardboard, and set over the threaded rods.