

Step A

Measure distance from edge of dock to the front of the swivel cleat. Make a mark at 2-1/2" from the front of the swivel cleat to the edge of the dock. The middle of the doggydocks hinge must be at the edge of the dock or swim platform

Step B

Using the base as a template, measure and mark hole locations.

Step C

Drill pilot holes, use size 17/64" drill bit

Step D

Place 1/4-20 washer and 1/4" x 3" Machine bolt through the bottom of the swivel cleat base and the mounting surface

Step E

Depending your specific set up, you can drill holes from beneath your dock or you can use lag bolts to secure the base into your docks or mounting platform. Once the base is secured to the dock.

Step F

Place swivel cleat top over the 3.5" tap bolt place washer and black round Knob to tighten.

Step G

Place doggydocks cleat cut out over the swivel cleat loosen black knob, turn top 90 or 180 degrees, and tighten down so the doggydocks is secure and has no movement.

Hardware Contents:

1. Swivel Cleat Base (Mounts to Dock or Swim Platform)
2. Swivel Cleat Top (Rotates and locks down doggydocks.
3. (2) 5/16" Machine Thread Tap Bolts
4. (2) 11/16" x 5/16" Flat Washers
5. (2) 5/16" Nylon Insert Lock Nuts
6. (1) 1/4-20 Machine Thread Tap Bolts
7. (1) 1/4-20 Wing Nut
8. (1) 1/4-20 Flat Lock Washer
9. (1) 1/4-20 Flat Washer
10. Drill Pilot Holes. Use a 17/64 Bit

